L-Cool Keyboard

The L-Cool is a water-resistant, open style, full sized value keyboard. It's closed deck construction, and drain holes in the base, make it easy to wash and dry quickly. The short cable makes it fast and easy to disconnect from workstations. And the keys on the L-Cool keyboard can be locked so it's easier to clean.

Weight:

420.0 g (0.9 lb.)

Dimensions:

440 mm x 138 mm x 19.0 mm 17.3" x 5.4" x 0.75"

Cable Length w/Extension Cable: 1.5m (4.9')

Operating temperature: 0 °C - 70 °C 32 °F - 158 ° F

Cable length: 0.15m (5.9") Power Consumption:

5V / 35mA

System requirements: USB interface (Not Compatible with PS/2)

Number of keys: 103 US Layout keys with Keypad

Warranty period: One year warranty

Specifications subject to change without notice

Installing Your L-Cool Keyboard:

USB: Attach the keyboard cable to a USB computer port. (You do not have to turn off your computer. There is no software to install.)



You can email us at: info@mmimd.com or call us at: (301) 341-4900 In Europe, contact +31-23-5450185 www.man-machine.com



Cleaning Instructions for Waterproof Keyboards and Mice:

- Clean the surface of the keyboard by wiping, brushing, spraying or dipping it. Use only rags, sponges or soft bristle brushes. DO NOT place the USB connector into the fluid.
- Either wipe with a dry cloth or allow to air dry.

To Lock your L-Cool Keyboard for Cleaning:

- Press "FN" key and Press "F11" key to lock keyboard.
- Keyboard may now be cleaned without disconnecting USB cable from PC.
- To unlock keyboard, Press "FN" key and Press "F11" key.

Disinfectants recommended by Man & Machine, Inc.:

- Chlorine based (max 10% solution) Chlorox, Novalsan, etc.
- Formaldehyde based Formaldehyde Solution 37%, Vinco Formaldegen, etc.
- Glutaraldehyde based Aldacide 200, Lysofume, Wavicide, etc.
- Phenol based Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- Alcohol based Cavicide, Isopropyl Alcohol, Medicide, etc.
- Oxidizing Hydrogen Peroxide 3% Solution, Lifegard Series, etc.
- Quaternary Ammonium Roccal-D, Bacto-Sep, Parvosol, etc.
- Soap and water

DO NOT USE:

- Petroleum based cleaning fluids, such as Gasoline
- Acetone
- Over 10% bleach solutions
- Temperature or pressure sterilization
- Buffing pads or scrubbing pads

USE OF PRODUCTS CONTAINING PETROLEUM OR ORGANIC ACID COMPONENTS IS STRICTLY PROHIBITED WITH THIS KEYBOARD. USE OF THESE WILL VOID MANUFACTURERS WARRANTY

THESE INSTRUCTIONS AND RECOMMENDATIONS HAVE BEEN PREPARED TO ADVISE THE PROPER METHODS FOR CLEANING YOUR PRODUCT. MAN & MACHINE, INC. OR THE LOCAL DISTRIBUTOR CANNOT ASSUME ANY RESPONSIBILITY FOR THE APPLICATION OF THEM. IF THERE ARE ANY QUESTIONS, PLEASE CONTACT PLACE OF PURCHASE OR MMI PRIOR TO CLEANING.